




UMC Inc.

BT-4B BOLT ON TOWABLE HUB
04301-114A

BOLT-ON TOWABLE BT-4B
RETAIL PARTS/MATERIAL LIST
04301-114A

ITEM	QTY	DESCRIPTION	PART #
1	1	SHAFT, BT-4-B SINGLE PIN	04301-211A
2*	1	SEAL, GREASE 2.625 ID x 3.5 OD	04301-701A
3	2	BEARING, CONE 2.00 ID (LM 104949)	06141-806A
4	2	BEARING, CUP 3.25 OD (LM 104911)	06143-802A
5	1	HUB, BT-4-B SINGLE PIN	04301-212A
6	1	WASHER, LOCK TAB M50 X 2mm THICK	04301-802B
7	1	NUT, LOCK M50 X 1.5	04301-801A
8	3	SCREW, HX HD ¼ -20 X .5LG	04301-806A
9	1	FITTING, RELIEF 1-5 PSI (ALEMITE 321839)	06140-702A
10	1	CAP, BOLT-ON HUB BT-4	04301-203A
11**	1	FITTING, LUBE M10 SAE TYPE	04301-803A
12	7	NUT, WHEEL LUG 9/16-18	06142-801A
13	2	BOLT, RNCB 9/16-18 X 1 7/8	04300-802A
14	5	BOLT, RNCB 9/16-18 X 1 5/8	06143-801A
15	1	WASHER, TONGUED 50mm X 4mm THICK	04301-807B

* Note: Item 2 alternate is " 04300-701A" Oil Seal (AD-7823EO NOK) or (26186 CR). Install alternate Oil Seal with the "Lip Spring" towards the Hub.

SEE MAINTENANCE MANUAL FOR PROPER SEAL INSTALLATION

** Note: Item 11 alternate is fitting 06140-701A (ALEMITE 1644-B), use thread sealer.