



WHEEL GEARBOX 725-TNT ** RETAIL PARTS / MATERIAL LIST

10140-101A

ITEM	QTY	DESCRIPTION	PART #
1	4	SCREW, HEX HEAD CAP ¼-20 x .75	06141-801A
2	1	COVER, EXPANSION CHAMBER (TNT SERIES)	10140-218A
3	1	DIAPHRAGM, RUBBER	06143-704A
4	1	HOUSING, DRIVE TNT UNIVERSAL	10140-202A
5	1	WORM, TNT SERIES 50:1	10140-201A
6	2	PLUG, PIPE ½" NPT	06141-803A
7	2	BEARING, CONE 1.1875" ID	06141-804A
8	2	BEARING, CUP 2.5312" OD	06141-805A
9	A/R	SHIM, INPUT (VARIOUS SIZES)	10141-209*
10	2	O-RING 4mm x 86 mm ID	10140-702A
11	4	SEAL, OIL 1.000 X 1.750 X .25 (INPUT)	06141-703D
12	2	CAP, END TNT SERIES	10140-207A
13	A/R	SHIM, O/P 2 ¼" ID (VARIOUS SIZES)	06145-203*
14	8	SCREW, HEX HEAD CAP 3/8-16 x 1.0 LONG	06141-802A
15	1	GASKET, COVER (10.19)	06141-706A
16	1	BEARING, CUP 3.250" OD	06143-802A
17	1	BEARING, CONE 2.000" ID	06141-806A
18	1	KEY, ½" SQ x 2.88" LONG	06141-809A
19	1	RING, SNAP 1.880" ID	06141-808A
20	1	GEAR, 50:1 2 ¼" ID UNIVERSAL	06147-209A
21	1	SPACER, TNT SHAFT	10140-206A
22	1	SEAL, OIL 2.250 X 3.000 X .43 OUTPUT (TRIPLE LIP)	06145-701E
23	1	COVER, GEARBOX 2 ¼" TNT	06147-211E
24	1	SHAFT ASSY, OUTPUT 2 ¼" TNT	10140-220A
25	8	NUT, LUG 9/16-18	06142-801A
26	1	BEARING, CONE 2 ¼" ID	06145-802A
27	1	BEARING, CONE 3 13/16" OD	06145-801A
28	8	WASHER, LOCK SPRING ¼"	06147-802A
29	2	SEAL, SHAFT FACE RUBBER 1.0000"	06147-707A
30	1	SHAFT PROTECTOR CAP – RED	06147-903A
31	1	GUARD, SHAFT (HUB CAP)	06147-218A
32	2	DUST CAP, TNT	10140-205A
33	1	END PLATE, STANDARD TNT	10140-203A
34	2	BEARING, WASHER TNT	10140-208A
35	18	SCREW, HX HD CAP 5/16 – 18 X 1	10140-801A
36	2	LUBE FITTING, DRIVE TYPE 3/16" DRILL	08790-803A
37	1	HANDLE, TNT	10140-204A
38	1	LOCK PIN, 3/8"	10140-217A
39	1	END PLATE, COMMON TNT	10140-223A
40	2	FITTING CAP, RED	04301-902A